




# JUNO PL LED<sup>IQ DALI</sup>

oktalite



## JUNO PL LED<sup>IQ DALI</sup>



- DE Montageanleitung
- EN Installation instructions
- FR Notice de montage
- IT Istruzioni per il montaggio
- ES Instrucciones de montaje
- RU Инструкция по монтажу

Oktalite Lichttechnik GmbH  
Mathias-Brüggen-Straße 73  
50829 Köln, Germany  
T +49 221 59767-0  
F +49 221 59767-40  
mail@oktalite.com  
www.oktalite.com

© Oktalite Lichttechnik GmbH, 2021



TK 10232707 · 20072191-01

# JUNO PL LED<sup>IQ DALI</sup>

**DE** Hierzu gehören die allgemeinen Montagehinweise TK 10166740. Vor Montage/Inbetriebnahme die Anleitungen lesen. Technische Änderungen vorbehalten!

**EN** This includes the general installation instructions TK 10166740. Before mounting/putting into operation read the instructions. Subject to technical changes!

**FR** En font partie les instructions générales de montage TK 10166740. Lire les instructions avant le montage/mise en service. Sous réserve de toute modification technique !

**IT** Ne fanno parte le istruzioni generali per il montaggio TK 10166740. Leggere le istruzioni prima del montaggio/della messa in esercizio. Con riserva di modifiche tecniche!

**ES** Aquí corresponden las indicaciones generales de montaje del modelo con el TK 10166740. Lea las instrucciones antes del montaje/puesta en funcionamiento. Nos reservamos el derecho de realizar modificaciones técnicas.

**RU** К ним относятся общие инструкции по установке ТК 10166740. Прочитайте инструкцию перед установкой / вводом в эксплуатацию. Мы оставляем за собой право на технические изменения!

